

Saje®

NATURAL WELLNESS



aromaOm®

ULTRASONIC DIFFUSER
DIFFUSEUR ULTRASONIQUE

Please read and save this manual



aromaOm[®]

ULTRASONIC DIFFUSER
DIFFUSEUR ULTRASONIQUE

*Live healthier by improving
the quality of the air you breathe*

TABLE OF CONTENTS

Benefits of Diffusing	1
Recommended Sage Diffuser Blends	2
Product Features	3
Specifications	4
Diagram of Parts	5
Operating Instructions	6-7
Care & Maintenance	8-9
Cautions	10-11
FAQs	12-13

BENEFITS OF DIFFUSING

Ultrasonic diffusers support healthy indoor air quality.

Ultrasonic technology, combined with water and a diffuser blend, produces negative ions and aromas that elevate your well being.

Diffusing helps to reduce dust, pet dander and other airborne allergens (like dust mite matter) from the air you breathe. When used with your favourite Saje diffuser blend, the ultrasonic diffuser's refreshing mist brings the benefits of nature into your space while supporting balance and harmony.

Transform your surroundings with clean air that's reminiscent of mist from a waterfall. Add the Saje diffuser blend of your choice and enjoy fresh, inviting aromas in your space.

RECOMMENDED SAJE DIFFUSER BLENDS:

SOOTHING AND RELAXING:

- Unwind | Tranquility | Stress Release

COUGH, COLD AND ALLERGY RELIEF:

- Immune | Allergy Release

FRESH, CLEAN AIR:

- Refresh | Exhale | Rain Forest

SPA-LIKE EXPERIENCE:

- Spa Spirit | Mountain High | After the Rain

ENERGIZING AND UPLIFTING:

- Energy | Quick Study

USE ONLY SAJE DIFFUSER BLENDS; USING OTHER OILS MAY RESULT IN MALFUNCTION.

PRODUCT FEATURES



- Uses an ultrasonic, heat-free system to disperse essential oil molecules into the air.
- May also be used as an air purifier or humidifier.
- Energy efficient, whisper-quiet operation and auto shut-off.
- Continuous and intermittent mist output settings.
- Operates with light on or off.
- Decorative cement cover.

SPECIFICATIONS


Product Name	aromaOm®
Input Voltage	AC100-240V
Output Voltage	DC24V
Rating Power	12W max.
Water Tank Capacity	100 ml (3 fl. oz.)
Misting Duration	approx. 3 hours continuous; approx. 6 hours intermittent (30 sec on/30 sec off)
Mist Output	approx. 30 ml (1 fl. oz.) per hour on continuous; approx. 15 ml (3 tsp) per hour for intermittent
Settings	light on/off control; continuous mist or intermittent mist; off
Light Options	white LED light on/off control during any setting
Coverage Area	approx. 200-400 sq ft
Dimensions	approx. (D) 90 mm x (H) 232 mm or (D) 3.5" x (H) 8"
Net Weight	approx. 624 g (22 oz)
Main Materials	outer cover: cement; base: ABS; water tank: PP; O-ring: silicone

DIAGRAM OF PARTS

- A. Cement Cover
- B. Water Tank Cover
- C. Mist On/Off Button
- D. LED Light On/Off Button
- E. Ceramic Disc
- F. Water Tank
- G. Maximum Water Level Line
- H. Air Outlet
- I. Silicone O-Ring
- J. LED Light
- K. DC Power Jack
- L. Power Adapter
- M. Base



OPERATING INSTRUCTIONS



1. Connect power adapter to DC power jack on bottom of the unit
2. Remove the cement cover from the base, then remove the water tank cover from the water tank.
3. Fill water tank with room temperature tap water to no higher than max. Water level line (100ml/3 fl. oz.). Tilting the unit can cause water to run into the diffuser's ventilation system and out the bottom - to ensure correct usage, always bring water to your ultrasonic diffuser and not the other way around.

4. Add 10-15 drops (depending on preference) of your favourite Saje diffuser blend to the water.



- Replace the water tank cover and then the cement cover; ensure that the cement cover is pressed down over the silicone o-ring.
- Plug power adapter into electrical outlet.
- Press the on/off button (right button) and select the mist setting.

BUTTON INDICATORS



1st stage-continuous misting:

PRESS ONCE: Mist emits continuously, automatically turns off after 3 hours of operation



2nd stage-misting intervals of 30 seconds:

PRESS A SECOND TIME: Mist emits at intervals of 30 seconds, automatically turns off after 6 hours of operation



3rd stage-power off:

PRESS A THIRD TIME: Mist off



3rd stage-power off:

LED night light on / LED night light off

- Unit will shut off automatically after 3 hours (continuous setting) and 6 hours (intermittent setting). Note that the water level remaining in the tank after shut-off will vary. For next use, fill up water level to the max. Water level line with new water supply.
- A filled unit should never be moved. Always wait until water reaches minimum levels to change diffuser's location; this will deter water from entering the ventilation system.
- Use only Saje diffuser blends; using other oils may result in malfunction.

PLEASE NOTE: RUN TIMES AND AMOUNT OF WATER LEFT IN THE TANK AFTER AUTO SHUT-OFF WILL VARY DUE TO CLIMATE, ENVIRONMENT AND OTHER FACTORS.



CARE & MAINTENANCE

- If the unit is knocked over while in operation, water could leak into the internal mechanism of the unit. If this occurs, unplug from power, empty water and let unit dry out in well-ventilated area for at least three days.
- Turn off unit and unplug from the power adapter prior to cleaning.
- Remove cover and empty water from the water tank, carefully avoiding the air outlet on the side of the tank.
- If required, use a clean, soft, damp cloth to wipe down exterior of unit.
- Frequency of cleaning is dependent upon usage and types of diffuser blends used (i.e. how thick the essential oils are in the diffuser blend).
- To clean inside water tank, dispense a few drops of rubbing alcohol into tank and wipe with a clean, soft cloth.
- To clean ceramic disc at bottom of water tank, dispense a few drops of rubbing alcohol onto a clean cotton swab and wipe clean.

- The ceramic disc should be kept clean of mineral deposits and other debris for optimal misting. Never use any sharp objects to clean the ceramic disc as this will damage the disc permanently.
- For optimum results, clean the water tank before changing diffuser blends.
- Do not disassemble or attempt to repair unit; in the event of a problem, please contact 1-877-ASK-SAJE.

CAUTIONS

- Only use the power adapter supplied with the device.
- Never operate the device if the power adapter is damaged.
- Do not use if any part of the device is broken.
- To reduce the risk of electric shock, do not attempt to service the device in any way other than as described in the "Care & Maintenance" section of this manual.
- When moving the device, hold securely by the base.
- Cement cover is fragile, please handle with care when placing and removing cover from the base in order to avoid chips and breakage.
- Do not touch the highly sensitive ceramic disc with bare fingers when the ultrasonic diffuser is in use or plugged in.
- Always place the unit on a stable, level surface.
- Do not fill water tank directly from tap as water could spill into the internal mechanism and cause damage.
- Ensure that no essential oils or water leak into the air outlets on either side of the water tank.
- Do not plug the unit into the wall socket with wet hands.

- To prevent damage to the ceramic disc, only use tap water at room temperature.
- Do not pour water or other liquid into the air outlet.
- Do not tilt, move or attempt to empty or refill unit while in operation.
- To prevent clogging and damage to the ceramic disc, always use clean water.
- Remove any liquid left in the water tank after each use.
- Always turn off and unplug the device during maintenance or when not in use.
- Ensure that the power adapter is not covered or blocked when plugged in; it must be able to dissipate the heat properly.
- Use only Saje diffuser blends; other oils may contain fragrances, base oils or synthetics that could result in malfunction. Some single note essential oils are also too thick or heavy for use in the ultrasonic diffuser. See FAQs for more information.
- In case of smoke, unusual aroma, undue noise or other malfunction, unplug the unit immediately and discontinue use. Further use may result in fire or electrical electric shock.
- Do not overfill or immerse the unit in water.
- Always keep unit out of reach of small children and pets.

FAQs

Q: WHAT IF MY UNIT DOES NOT TURN ON?

Power adapter may not be properly plugged in; ensure that the power adapter is properly plugged into the DC power jack and the electrical source.

Q: WHAT IF MY UNIT DOES NOT MIST OR THERE IS ALMOST NO MIST?

There may not be enough water in the water tank; ensure that the water tank is filled to the maximum water level line.

The water level may be too high (higher than the maximum water level line); pour out excess water and try again.

The ceramic disc may require cleaning. Please see "Care & Maintenance" instructions.

Q: WHAT TYPE OF WATER SHOULD GO INTO MY ULTRASONIC DIFFUSER?

To prevent damage to the unit, it's recommended to use room temperature tap water. To prevent clogging and damage to the ceramic disc, always use clean water.

Q: WHAT CAN I PUT IN MY ULTRASONIC DIFFUSER?

Use only 100% natural Saje diffuser blends; other blends and oils may contain fragrances, base oils or synthetics that could result in malfunction.

Many single note essential oils should not be used in the ultrasonic diffuser. Single note essential oils may have a thick or heavy consistency that can clog the ultrasonic diffuser and cause it to stop working.

Saje diffuser blends have been carefully blended to be effective for you, and are safe and easy to use in your ultrasonic diffuser.